

Glue advice

sense
THAT MAKES SENSE

for use at SENSE dryback series: R | P | PP | V | VLN | T | X

The dryback LVT (PVC) design floors have to be glued completely to the flat levelled subfloor.

The glues, in the overview below, are tested in combination with our drybacks by some glue producers and are therefore guaranteed. Only use A2 trowel with 2 mm teeth.

Producent	Merk & artikel
Frencken	FV 312
Bostik	STIX A550 Power Elastic (hard elastisch) STIX A800 Premium (zacht elastisch) STIX P956 2K (voor natte ruimtes)
Bijlard	Bijlard FLOOR pvc-lijm
Wulff	Ultrastrong Suprastrong (vezelversterkt) Multistrong (vezelversterkt)
Thomsit	K 188E K 150 - K 190F (vezelversterkt) UK 800
Uzin	KE 66 KE 2000 S KR 430 (2-componenten)
Wakol	D 3330 D 3307 D 3318 - D 3319 (vezelversterkt) D 3360 - D3320 - D 3125 PU 270 (2-componenten) MS 550 - MS 552
Mapei	Ultrabond Eco 4 (tegen wand) Ultrabond Eco Tack
Stauf	D 50 (vezelversterkt) D 37
F. Ball & Co	F44 F46 F48+ F49 (permanent) F74 F81 F84 (voor natte ruimtes) F49 F60 F66 (tegen wand)
Kerakoll	SLC R3+ SLC Eco 45/3

The advised glues must be strictly applied according to the conditions of the glue producers.

Glues not mentioned in the above overview are not tested.

Only the listed glues are guaranteed.

Glues which have to be rolled are not advised because of the less fixing power and therefore more chance on dimensional size changes.

Use only fiber reinforced glues, out of the above overview, behind big windows through which a lot of sunlight is shining. Also use on wooden subfloors.

SENSE is a product of Prodinex - www.prodinex.com